## **CONSTANT FLOW REGULATOR**

| EFR                               | -    |
|-----------------------------------|------|
|                                   |      |
| EFR3                              |      |
| For ELF-Meters                    | 3LF  |
| For ELF/L-Meters with back plates | 3BP  |
| For L-Meters                      | 3EK  |
|                                   |      |
| EFR14                             |      |
| For EM and ESF meters, 3 mm valve | 14/3 |
| For EM and ESF meters, 6 mm valve | 14/6 |
| For EM and ESF meters, 9 mm valve | 14/9 |